



Step 1: Open and unfold float tube on a flat surface



Step 2: Disconnect all straps and unzip zippers



Step 5: Unzip cover and align bladder seams (part 4) with the cover's bottom zipper (part 7)



Step 6: Zip cover and continue inflating until 1/2 full



Step 3: Locate the bladder valves (parts 1-3) and guide them through the grommets until securely aligned



Step 4: With cover closed, inflate float tube 1/3 full



Step 7: Open cover and adjust bladders making sure the valve is straight and not pulling on hole. If bladder is not properly in place, the valve will want to pull sideways or even out of the hole.



Step 8: Resume inflating until completely full. Small wrinkles should be left in cover when properly inflated.



Do Not  
Over Inflate!

Maximum  
Inflation 2.5 PSI

Note:

- Once inflated, make sure both valve caps are firmly tightened. If they are not tightened, it can cause bladder leakage.
- After you successfully inflate your float tube using these instructions, you will not need to adjust or re-align the bladders again, unless you remove the bladders from cover.